

# prophete

## User manual Battery pump



### Notes on these instructions

- Before using the product for the first time, please read these instructions carefully. This will help you become familiar with the product more quickly and avoid operating errors that could lead to damage or accidents. Pay particular attention to the safety and hazard warnings.
- Keep these instructions and include them with any purchase of the product.
- The latest version of these instructions is available for download on our website.

### General Safety Instructions

#### RISK OF ACCIDENT & DAMAGE!

- This product can be used by children aged 8 years and older, as well as by persons with reduced physical, sensory, or mental capabilities or lack of experience and knowledge, if they have been supervised or instructed in the safe use of the device and understand the hazards involved.
- The device may become hot during operation. Avoid contact with the adapter immediately after inflation.
- The device will automatically switch off after 3 minutes of continuous inflation to prevent overuse. If the object being inflated is too large and the target pressure is not reached, the process can be restarted. Do not use the device for more than 5 minutes at a time and allow it to cool for at least 15 minutes before using it again.
- The air inlet must not be covered during inflation.
- Observe the maximum pressure of the object being inflated, as it may burst if inflated too high.
- The permissible measuring range must not be exceeded, as this may damage the sensor.
- The product is not waterproof. Do not use or charge in humid environments or in the rain.
- If you notice smoke, unusual noises, odors, or heat, discontinue use. Do not use if it is obviously defective or damaged.
- The product contains a battery. Therefore, never throw it into fire, immerse it in liquid, microwave it, short-circuit it, expose it to high temperatures, or subject it to extremely low air pressure.
- Only charge the battery using a USB power adapter and a standard USB-C cable. Refer to the USB power adapter's user manual. Ensure the device is clean and dry before charging. Disconnect the device from the power source once charging is complete.
- Do not modify the product.

### Package contents



- 1 x Battery-powered pump
- 1 x USB charging cable
- 1 x Adapter set
- 1 x User manual
- 1 x Storage bag

### Operation

#### CHARGING THE BATTERY

To ensure proper use, fully charge the device before use. You can charge it, for example, with a USB power adapter or a USB power bank.

To do this, connect the charging cable to the USB charging port **06** and the power source. The battery indicator **02** will flash during the charging process.

Disconnect the charging cable after charging is complete.

#### SWITCHING THE DEVICE ON/OFF

1. Press and hold the button **04** for approximately 3 seconds to switch the device on or off.

The device will switch off automatically after one minute if it is not used.

#### CHANGING THE UNIT

1. Briefly press the plus and minus buttons **05** simultaneously to change the unit (psi/bar). The currently selected unit will be displayed **03**.

#### ADJUSTING THE ADAPTER

The adapter consists of three interlocking adapter components and can be adapted for different valves:

For Presta and Dunlop valves **07**, assemble the adapter components as shown. Ensure that the rubber piece with the small hole faces outwards.

For Schrader valves **08**, the rubber piece with the large hole must face outwards.

#### ATTACHING THE ADAPTER

1. Screw the required adapter into the socket of the battery pump **09**.

#### INFLATING

1. Use the plus/minus buttons **05** to select the desired target pressure and wait briefly until the display flashes. The target pressure is now saved.
2. Press the pump firmly onto the valve.
3. Start the inflation process by briefly pressing the button **04**. The display **01** will show the current pressure.  
If you hear a hissing sound or the pressure is not displayed correctly, adjust the position or angle of the pump. The inflation process will stop automatically once the target pressure is reached.

If the pressure remains below 5 PSI (0.3 bar) during inflation, the device will switch off automatically.

### Technical data

MODEL	Prophete battery pump (7306)
WORKING RANGE	3-120 psi / 0.2-8.3 bar
MEASURING RANGE	3-150 psi / 0.2-10.3 bar
CHARGING PORT	USB-C (5V)
BATTERY	Li-ion (500 mAh)
OPERATING TEMPERATURE	-10°C to 45°C
PRODUCT WEIGHT	approx. 150 g

### Care and storage instructions

Keep the product clean to ensure safe and effective use. You can clean the product surface by hand with a damp cloth. Use only solvent-free, non-corrosive cleaning agents.

Always recharge a depleted battery as soon as possible.

Store the product in a cool, dry place. Fully charge it once a month.

### Warranty information

We provide the statutory warranty period for this product. This period begins on the date of purchase (receipt, proof of purchase). During the warranty period, defective products can be reported to the seller or to the specified service address. During this period, all defects attributable to material or manufacturing defects will be repaired free of charge. This excludes normal wear and tear or damage caused by accidents, improper use, drops/impacts, or modifications to the product. Repair or replacement of the product does not start a new warranty period.

### Disposal Instructions



Consumers are legally obligated to dispose of electrical and electronic equipment separately from household waste at the end of its service life. This ensures environmentally sound and resource-conserving recycling. You can drop off these items at collection points operated by public waste management authorities or at collection points established by manufacturers or distributors in accordance with the German Electrical and Electronic Equipment Act. Disposal of old equipment is free of charge. Consumers have the option of returning an old device free of charge to a distributor obligated to take back such equipment if they purchase an equivalent new device with essentially the same function. Dispose of the packaging in an environmentally sound and sorted manner in the provided collection containers. You can find out more about disposal options from your local council or city administration.

### EC Declaration of Conformity



You can download the EC Declaration of Conformity at [www.prophete.de](http://www.prophete.de).

### Contact/service address

Prophete In Moving GmbH  
Lindenstr. 50 | D-33378 Rheda-Wiedenbrück  
[www.prophete.de](http://www.prophete.de) | [info@prophete.de](mailto:info@prophete.de)